

INSTALLATION INSTRUCTIONS



67-69

1 1/8" Front Sway Bar

PART NUMBER 2735

Technical Support

We strive to provide the utmost pre- and post-sales support for our products. Whether you just need upgrade advice, or assistance in adjusting or installing a product, our experienced support staff is always ready to help optimize your UMI product.

CHAT WITH A UMI PROFESSIONAL TODAY

Need installation advice or clarification on the instructions? Scan the QR code (right) to chat directly with a UMI Professional or use the contact information provided to talk to customer service.

Note: UMI social media accounts do not respond to customer service questions.



CONTACT CUSTOMER SERVICE

Hours: M-F 8:00-4:30 (EST)

Email: support@umiperformance.com

Call: +1 (814) 343-6315

Address: 509 Hemlock Street
Philipsburg, PA 16866

SOCIAL MEDIA

#umiequipped #umiperformance

@umiperformanceinc

Included Parts

Part Description	Quantity	PN
1 1/8" Sway Bar	1 Piece	2735
Sway Bar Bushing	1 Kit	U-62528

Tools Needed

Properly rated Jack and Stands
SAE Hand tools, sockets, wrenches

INSTALLATION INSTRUCTION

DISCLAIMER

UMI Performance shall not be held liable for any injuries or damages resulting from the improper installation of this product. It is the sole responsibility of the user to ensure that the product is installed correctly and in accordance with all applicable laws, codes, and regulations. The user assumes all risk and liability for any injuries or damages that may arise from the improper installation of this product. It is important to follow these steps carefully and use the proper tools to avoid damaging the vehicle or causing injury to yourself. If you are uncertain about any part of the installation process, it is recommended that you seek the assistance of a professional mechanic.

STEP 1: Disassembly

- 1) Jack the vehicle up by placing the jack under the front cross-member. Place the (2) jack stands behind the front tires on the sub frame to allow the front control arms to unload.
- 2) Start by disassembling the old sway bar. Remove the end links from the sway bar and lower control arm, remove sway bar bushings from the frame. **Fig 1.**
- 3) Once the old sway bar is out, locate the new supplied sway bar bushings. Using the supplied grease, apply lube to the mating surface of the bar and sway bar bushing. **Fig 2.**
- 4) Install the Poly Bushing to the new sway bar.
- 5) Install the metal straps and lift the bar into place. Torque to the proper spec. **Torque to 35 ft. lbs.**
- 6) Reattach the factory end links, leaving them loose, place the car on cribbing or ramps and tighten at ride height. **Fig 3. Roughly 14 ft lbs or until the rubber bushings compress to the size of the metal washer.**
- 8) Make sure there are no clearance issues with any other parts by rotating the steering wheel back and forth.
- 9) Double check all hardware is tight and set the car back down on the ground.

FIGURES FOR REFERENCE

Fig. 1 Install New End Links




Fig 1. Remove the old sway bar.




Fig 2. Grease Bushings.



Fig 3. Sway bar bushings Tight.